GEFRAN

GTS-T 10/20/25; GTS 15/25/40/50/60/75/90/120A

POWER SOLID STATE RELAYS WITH LOGIC CONTROL





Main applications

- Plastic extrusion lines and injection presses
- Packing and packaging machines
- Polymerization and production plants for synthetic fibers
- Rubber vulcanization plants
- Driers for ceramics and
- construction elements · Chemical and pharmaceutical industry
- Industrial electric furnaces
- Food processing plants

GENERAL

Turning an electric load on or off requires the use of a suitable interrupt and protection device that is safe and immune to disturbances. In addition, for optimum process control in many industrial applications, it is indispensable to drive the load with very short switching times: the best solution is the use of solid state relays. Gefran proposes the GTS range of power solid state relays with voltage zero crossing, currents from 10A to 120A, and rated voltages of 230Vac and 480Vac.

Versions with TRIAC and with double SCR are available.

All models are designed to guarantee operation at rated currents, with continuous driving of power at 40°C working temperature.

For less critical operating conditions, you can use the products beyond rated currents (using the dissipation curves as reference).

Various accessories are available. such as the attachment for panel fastening, fuses and fuse holders.

TECHNICAL DATA

General features

Category of use: AC1

Rated working voltage

- 230Vac (max. range 24...280Vac)
- 480Vac (max. range 24...530Vac)
- Rated frequency: 50/60Hz Non-repetitive voltage:
- 500Vp for model with rated voltage 230Vac
- 1200Vp for model with rated voltage 480Vac Switching voltage for zero: < 20V Activation time: = 1/2 cycle Deactivation time: = 1/2 cycle Potential drop at rated current: = < 1.4Vrms

Power factor = 1

Control inputs

Max. input: < 10mA @32V Max. reverse voltage: 36Vdc

GTS -T10/T20/T25 (TRIAC version)

Control voltage: 5...32Vdc Activation voltage: > 4.2Vdc Deactivation voltage:< 2Vdc

GTS 15 ... 120A (versione SCR)

Control voltage: 6...32Vdc Activation voltage: > 5.1Vdc Deactivation voltage:< 3Vdc

Main features

- Input control from logic signal
- Switching at voltage zero crossing
- Versions with TRIAC and with double SCR in antiparallel.
- LED power on indicator
- MOV protections (varistor)
- Fastening to DIN bar (standard); fastening to panel (optional)

OUTPUTS

GTS –T10 (TRIAC version)

Rated current: 10 A@40°C in continuous service Non-repetitive overcurrent t= 20 ms: 30A I²t for blowout: 72A²s dV/dt critical with output deactivated: 500V/us

GTS –T20 (TRIAC version)

Rated current: 20 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 50A I²t for blowout: 315A²s dV/dt critical with output deactivated: 500V/µs

GTS –T25 (TRIAC version)

Rated current: 25 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 50A I2t for blowout: 315A2s dV/dt critical with output deactivated: 500V/µs

GTS 15 (SCR version)

Rated current:15 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 400A

 $I^{2}t$ for blowout: $\leq 450A^{2}s$ dV/dt critical with output deactivated: 1000V/µs

GTS 25 (SCR version)

Rated current: 25 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 400A I²t for blowout: ≤645A²s dV/dt critical with output deactivated: 1000V/µs

GTS 40 (SCR version)

Rated current: 40 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 600A I²t for blowout: ≤1010A²s dV/dt critical with output deactivated: 1000 V/µs

GTS 50 (SCR version)

Rated current: 50 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1150A I²t for blowout: ≤6600A²s dV/dt critical with output deactivated: 1000V/µs

GTS 60 (SCR version)

Rated current: 60 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1150A I²t for blowout: ≤6600A²s dV/dt critical with output deactivated: 1000V/µs

GTS 75 (SCR version)

Rated current: 75 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1300A I²t for blowout: ≤8000A²s dV/dt critical with output deactivated: 1000V/µs

GTS 90 (SCR version)

Rated current: 90A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1500A I²t for blowout:≤11200A²s dV/dt critical with output deactivated: 1000V/µs

GTS 120 (SCR version)

Rated current: 120A@ 40°C in continuous service (complete with fan Limits of use and standard thermostat) Non-repetitive overcurrent t=20 ms: 1500A I²t for blowout: ≤11200A²s

dV/dt critical with output deactivated: 1000V/uS

Isolation

Rated isolation voltage input/output: 2500VAC rms TRIAC version 4000VAC rms SCR version

Ambient conditions

Working temperature:

da 0 a 80°C (according to dissipation curves)

• Max. relative humidity: 50% at 40°C

Max. installation altitude: 2000m asl

- Pollution level : 3
- Storage temperature: -20..+85°C

Installation notes

Use the high-speed fuse specified in the catalog according to the connection example given. - Applications with solid state power units must also include an automatic safety switch to cut out the load power line. For maximum reliability, it is essential to install the device correctly in the panel in order to have adequate heat exchange between the sink and the surrounding air by natural convection.

Install the device vertically (max. 10° inclination to vertical axis)

 Vertical distance between a device and panel wall >100mm • Horizontal distance between a device and panel wall: at least 20mm Vertical distance between one device and another: at least 300mm. · Horizontal distance between one device and another: at least 20mm.

Make sure that the cable channels do not reduce such distances; if so, install the groups cantilevered to the panel so that air can flow vertically on the heat sink without obstructions.

 dissipation of thermal power of device with restrictions on temperature of installation site.

 requires exchange with outside air or an air conditioner to transfer dissipated power outside the panel. installation restrictions (distances) between devices to guarantee dissipation by natural convection) max. voltage limits and derivative of transients in line, for which the solid state unit has internal protection devices (depending on model). presence of dispersion current

< 3mA for SCR version GTSs and < 4mA 4mA for Triac version GTSs. (max. value with rated voltage and junction temperature of 125°C).

DESCRIPTION OF FACEPLATE / DIMENSIONS AND MOUNTING MEASUREMENTS



CONNECTION EXAMPLES

Single-phase connection



Three-phase Star connection with neutral



Three-phase Triangle or Star connection without neutral on two phases



DISSIPATION CURVES

Curves of rated current according to room temperature.



N.B.: Curves for the GTS 120 refer to the device complete with standard running.

TABLE OF TERMINALS AND CONDUCTORS

	CONTROL TERMINAL			POWER TERMINAL			GROUND TERMINAL •	
Size	Contact area (WxD) screwtype	isolated terminal	Max section. ** conductor tightening torque	Contact area (WxD) screw type	isolated terminal	Max section. ** conductor tightening torque	Contact area (WxD) screw type	Max section. ** conductor tightening torque
10/15/ 20A		Eye/fork/ Faston type conn*	6mm ² 0.6Nm Max	6,4x9 M3	Eye/fork/ conn tipo Faston*	6mm² 0.4-0.6 Nm	9x12 M5	6mm² 1.3-1.8 Nm
25A (GTS)	6,4x9	Eye/fork/ Faston type conn*	6mm ² 0.6Nm Max	6,4x9 M3	Eye/fork	6mm ² 0.4-0.6 Nm	9x12 M5	6mm ² 1.3-1.8 Nm
40A 25A(GTS-	6,3x9	Eye/fork/ tip	2.5mm ² 0.6Nm Max	12x12 M5	Eye/fork	16mm² 1.5-2.2 Nm	11,5x12 M5	16mm ² 1.5-2.2 Nm
50/60A	6,3x9	Eye/fork/ tip	2.5mm ² 0.6Nm Max	16x18 M6	Eye/fork	50mm ² 3.5-6 Nm	14x16 M5	50mm ² 1.8-2.5Nm
75-90A	6,3x9	Eye/fork/ tip	2.5mm ² 0.6Nm Max	16x18 M6	Eye/fork	50mm ² 3.5-6 Nm	14x16 M5	50mm ² 1.8-2.5 Nm
120A		Eye/fork/ tip	2.5mm ² 0.6Nm Max	16x18 M6	Eye/fork	50mm ² 3.5-6 Nm	14x16 M5	50mm² 1.8-2.5 Nm

(*) Female faston (for insertion, remove the M3 screw by making the nut re-enter the seat in the holder) (**)The max. sections specified refer to unipolar copper wires isolated in PVC..

• Note: For the ground terminal, you have to use an eye wire terminal.

(WxD) = Width x depth

ACCESSORIES

A wide range of accessories is available (including fuses and fuse holders, heat sinks, ID plates and thermostats).

To choose accessories, see the section "Solid state relays - Accessories."

ORDER CODE



Please contact GEFRAN personnel for information on availability of codes.

WARNING: this symbol indicates danger.

Read the following warnings before installing, connecting or using the device:

- follow instructions precisely when connecting the device.
- always use cables that are suitable for the voltage and current levels indicated in the technical specifications.
- In applications with risk of damage to persons, machines or materials, you MUST install auxiliary alarm devices.
- It is advisable to verify frequently that the alarm device is functional even during the normal operation of the equipment.
- DO NOT operate the device in rooms with dangerous (inflammable or explosive) atmosphere.
- During continuous operation, the heat sink can reach up to 100°C, and stays at a high temperature even after the device is turned off due to thermal inertia; therefore, DO NOT touch it and avoid contact with electrical wires.
- do not work on the power part without first disconnecting electrical power to the panel.
- do not remove the cover when the device is powered!

Installation:

• correctly ground the device using the specific terminal.

• power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.

- avoid dust, humidity, corrosive gases and heat sources.
- respect the installation distances between one device and another (to allow for dissipation of generated heat).
- to keep air in movement, we advise you to install a fan near the GTS group in the electrical panel containing the GTSs.
- respect the indicated dissipation curves

Maintenance: at regular intervals, check operation of the cooling fans and clean all air ventilation filters.

• repairs must be done out only by trained and specialized personnel. Cut power to the device before accessing internal parts.

• do not clean the box with solvents derived from hydrocarbons (trichloroethylene, gasoline, etc.). Using such solvents will compromise the device's mechanical reliability. Use a clean cloth moistened with ethyl alcohol or water to clean external parts in plastic. *Service:* GEFRAN has a service department. The warranty excludes defects caused by any use not conforming to these instructions.

GEFRAN spa reserves the right to make aesthetic or functional changes at any time and without notice.



This device conforms to European Union Directive 2004/108/CE and 2006/95/CE as amended with reference to generic standards: EN 61000-6-2 (immunity in industrial environment) EN 61000-6-4 (emission in industrial environment) - EN 61010-1 (safety regulations).

In Conformity with UL508 - File: E243386

