SOLID STATE RELAY - ACCESSORIES



GQ, GS, GZ, GT, GD, GTF, GFW ACCESSORIES

· Choose the smallest heatsink (starting from upwards), which

point [Tmax_a Imax] is in the gray working area of dissipation

HEATSINKS

DESCRIPTION

Different models of heatsinks have been designed and tested to meet size and dimension needs.

How to choose a heatsink

GEFRAN

- · Set max. air temperature inside the panelboard (Tmax_a)
- Set max. operating current: Imax = Inom. load + 10%
- Draw on the "graphs" Tmax_a, Imax points.

INSTALLATION

In order to obtain best reliability, it is important to install a heatsink correctly inside the panel, to reach an adequate thermal exchange between the device and the surrounding air in natural convection conditions.

curves

Respect installation distances

How to install it correctly:

Mount it vertically (max. 10° inclination from the vertical axis)

- · Vertical distance between a heatsink and the panel wall: 100 mm at leas.
- · Horizontal distance between a heatsink and the panel wall: 20 mm at least.
- · Vertical distance between two heatsinks: 300 mm at least.
- · Horizontal distance between two heatsinks: 40 mm at least.

Check that cable channels do not reduce these distances; should it happen, mount the relays overhanging from the panel, so that the air can flow vertically on the heatsink without obstables (see Fig.1).





DISSIPATION CURVES

Effective current controllable based on room temperature





Should the stated point [Tmax_a Imax] be outside the working area, it is necessary to equip the heatsink with a fan and a safety thermostat. **N.B.** The operating point has not to be outside the delimited area.

- DIS908/910 heatsinks are suitable for three-phase solid state relays of GZ series.
- Controlled three-phase effective current refers to the used line current of three-phase load.
- Heatsinks used with a cooling fan should be equipped with safety thermostat, so that the solid state relay can be switched off in case of fan failure.

(*) Data surveyed with 40°C ambient temperature and heatsink in vertical position surrounded by 15 cm free space; natural convection; contact surface with the heating element = ~ 8cm² [38mmx 20mm]

HEAT SINKS - ORDER CODE - AVAILABLE MODELS

| CODE | DESCRIPTION (dimensions HxLxP) | for SSR type | equipment |
|------------|---|--------------------|--|
| DIS-25G | heatsink in extruded aluminium 100x24x65 | GS 15/25A | M4 screws for relay fixing DIN rail mounting |
| DIS-25GD | heatsink in extruded aluminium 100x35x54 | GS ≤ 40A / GD | M4 screws for relay fixing DIN rail mounting |
| DIS-40G | heatsink in extruded aluminium 100x35x100 | GS ≤ 40A / GD40A | M4 screws for relay fixing DIN rail mounting |
| DIS-50G | heatsink in extruded aluminium 100x60x100 | GS ≤ 50A / GT / GQ | M5 screws for relay fixing DIN rail mounting |
| DIS-60G | heatsink in extruded aluminium 100x80x100 | GS ≤ 50A / GT / GQ | |
| DIS-90G | heatsink in extruded aluminium 100x126x100 | GS ≤ 50A / GT / GQ | |
| DIS-908 | heatsink in extruded aluminium 80x126x100 | GZ | |
| DIS-910 | heatsink in extruded aluminium 100x126x100 | GZ | |
| DIS-25G-1M | heatsink in extruded aluminium for group mounting SSR, with DIS-25G profile | | |
| DIS-40G-1M | heatsink in extruded aluminium for group mounting SSR, with DIS-40G profile | | |
| DIS-50G-1M | heatsink in extruded aluminium for group mounting SSR, with DIS-50G profile | | |
| DIS-60G-1M | heatsink in extruded aluminium for group mounting SSR, with DIS-60G profile | | |
| DIS-90G-1M | heatsink in extruded aluminium for group mounting SSR, with DIS-90G profile | | |



POWER SOLID STATE RELAYS ACCESSORIES

THERMOSTAT

DESCRIPTION

Safety thermostat is expressly designed to prevent overtemperature.

Thanks to the miniaturized case the thermal answer is excellent. Furtheron, the thermostat is a very good thermal protection, as it can be mounted very near to the critical point which has to be controlled.

When it is connected in series to control voltage, the thermostat disenergises the relay as soon as the critical operating temperature is reached. Relay is energised again when temperature drops underneath the critical value (about 90°C).

The thermostat is normally closed and opens when temperature exceedes 90°C (with automatic reset).

Connection in series with the input control is suggested. TGRZ is installed in one of the two slots of the GZ three-phase solid state relay case.

TGR is fixed by means of a small bracket and of a screw (enclosed).

The VIR-1 thermostat is supplied as a spare part for: $W21x \ge 150A$ solid state power units.

INSTALLATION



ORDER CODE - AVAILABLE MODELS

T-GR (includes fastening bracket) T-GRZ (for GZ) VIR-1 (for $W21x \ge 150A$)



SOLID STATE RELAY ACCESSORIES

VARISTORS (MOV)

Spark Suppressors for Solid State Relay Protection

DESCRIPTION

MOV (metal-oxide-varistor) is an overvoltage protection device which improves the reliability of solid state relays when functioning

| ORDER CODE | WORKING VOLTAGE (V) |
|------------|---------------------|
| RV03 | 120-290 Vac |
| RV04 | 291-400 Vac |
| RV05 | 401-500 Vac |



HEATSINKS ACCESSORIES

FANS

DESCRIPTION

An additional fan, applied to the heatsink of a solid state relay, improves its dissipation performance and allows the solid state relay to work at higher ambient temperatures with the same current. Fan installation benefits are shown (dashed) by the dissipation curves of the different heatsinks.

ORDER CODE - AVAILABLE MODELS

| Code | Description | Mechanical predisposition for heatsink type | Equipment | For SSR type |
|--------|---------------------------------------|---|---|-----------------------------------|
| VEN-60 | Fan kit 24Vdc, 4W 60x60x25 | DIS-50G DIS-60G | hand guard nr. 4 screws nr. 4 plastic fastening rivets for direct attachment to heatsink | |
| VEN-90 | Fan kit 230Vac, 14W, 50Hz 80x80x40 | DIS-90G DIS-910 DIS-908 | hand guard nr. 4 M4 screws nr. 4 notched washers nr. 4 plastic fastening rivets for direct attachment to heatsink | GTS 120A GTT 120A GTZ ≥ 40A |
| VEN-91 | Fan kit 115Vac, 14W, 50Hz 80x80x40 | DIS-90G DIS-910 DIS-908 | hand guard nr. 4 M4 screws nr. 4 notched washers nr. 4 plastic fastening rivets for direct attachment to heatsink | GTS 120A GTT 120A GTZ ≥ 40A |
| VEN-92 | Fan kit 24Vdc, 4W 80x80x25 | DIS-90G DIS-910 | hand guard nr. 4 M4 screws nr. 4 notched washers nr. 4 plastic fastening rivets for direct attachment to heatsink | GTS 120A GTT 120A GTZ ≥ 40A |

ACCESSORIES GTF / GFW

ORDER CODE - AVAILABLE MODELS

| Code | Description | Mechanical predisposition for heatsink type | Equipment | For SSR type |
|--------|--------------------------------|---|---|-----------------------------------|
| VEN-60 | Fan kit 24Vdc, 4W 60x60x25 | DIS-60G | hand guard D60 nr. 4 screws M2 + notched washers nr. 4 plastic fastening rivets cavo intestato con puntalini | GTF40, 50 El.Fuse |
| VEN-62 | Fan 24Vdc, 4W, 60x60 | Da in <mark>serire nella</mark> griglia GRI-4 | cavo intestato su connettore 3 poli | GTF150 GFW40,60,100,150 |
| VEN-63 | Fan 24Vdc, 4W 60x60 | Da inserire nella griglia GRI-4 | cavo intestato su connettore 3 poli | GTF200, 250 GFW200,250 |
| VEN-92 | Fan kit 24Vdc, 4W 80x80x25 | DIS-90G | hand guard D80 nr. 4 M4 screws + notched washers nr. 4 plastic fastening rivets cavo intestato con puntalini | GTS 120A GTF60 El.Fuse |
| GRI-4 | Grig <mark>lia ve</mark> ntola | | | GTF150,200, 250 GFW150,200,250 |
| FLT-4 | Filtro per ventola | | | GTF150,200, 250 GFW150,200,250 |

ACCESSORIES SUPPORT FOR DIN BAR

PANEL ATTACHMENT SUPPORT



ORDER CODE - AVAILABLE MODELS

| Code | Description | For SSR / Heatsink type | Equipment |
|---------|---|---|---|
| DIN-2 | support for attachment to DIN bar | GTS 15/25A DIS15G, DIS25G | fastening screws |
| DIN-4 | support for attachment to DIN bar with spring | W211 25/40/75/100/150A W212 25/40/75/100/150A | fastening screws |
| DIN-5 | support for attachment to DIN bar with spring | GTS, GTD, GTT, GTZ, DIS15G, DIS25GD, DIS25G, DIS40G, DIS50G, DIS60G, DIS90G, DIS908, DIS910 | fastening screws |
| F19672 | socket for relays with attachment to DIN bar | GTS-L 5/10/15A | fastening screws |
| PAN-1 | kit attachment to panel | GTS, GTT, | nr. 2 plastic supports nr. 2 screws nr. 4 washers |
| 1886001 | kit attachment to panel | Wattcor series | |



SOLID STATE RELAY ACCESSORIES

COVERS FOR SOLID STATE RELAYS



ORDER CODE - AVAILABLE MODELS

| Code | Description |
|-------------|--|
| COP-GS-0 | Pad-printed cover for GS-T 10A, 20A and GS 15A, 25A. |
| COP-GS-1 | Pad-printed cover for GS-T 25A and GS40A. |
| COP-GS-2 | Pad-printed cover for GS 50A, GS 60A, GS 75A, GS 90A, GS 120A. |
| COP-GD-0 | Pad-printed cover for GD40. |
| COP-GTS-0 | Pad-printed cover for GTS-T 10A, 20A and GTS 15A, 25A. |
| COP-GTS-1 | Pad-printed cover for GTS-T 25A and GTS 40A. |
| COP-GTS-2 | Pad-printed cover for GTS 50A, 60A, 75A, 90A, 120A. |
| COP-GTD-0 | Pad-printed cover for GTD-25 |
| COP-GTD-1 | Pad-printed cover for GTD-40 |
| COP-GT-0 | Pad-printed cover for GT 25A, 40A, 50A, 60A, 75A, 90A, 120A. |
| COP-GTT-0 | Pad-printed cover for GTT 25A, 40A, 50A, 60A, 75A, 90A, 120A. |
| COP-GTS-L-0 | Cover for GTS-L5 |
| COP-GTS-L-1 | Cover for GTS-L10 / GTS-L15 |
| BBR | Protective cover for RA single-phase solid state relays |

HIRAZ 1 HIRAZ 1 KIVA 25 KIVA 25 C 7787 URL 025 C 77672

SOLID STATE RELAY ACCESSORIES

FUSES AND FUSE HOLDERS

DESCRIPTION

These fuses ensure the maximum safety in solid state relay applications. Fuses with a very high cutoff power are used for this kind of applications.

MODEL SELECTION

GS-L / GTS-L / GTS-T / GTS / GS / GS-T / GTD / GTT (single-phase with antiparallel thyristor or Triac)

| Relay | i^2t | Nominal voltage | Fuse | Dimensions (mm) | Fuse order code | Fuse holder order code | Notes |
|---------------------------------|------|--------------------|------|--------------------|-----------------------|---------------------------|---------|
| GS-L5 / GTS-L5 / GTS-L4-5 | 45 | 230 440 | 5A | 10x38 | FUS-06-L | PF-10x38 | plug-in |
| GS-L10 / GTS-L10 / GTS-L4-10 | 100 | 230 440 | 10A | 10x38 | FUS-10-L | PF-10x38 | plug-in |
| GS-L15 / GTS-L15 / GTS-L4-15 | 180 | 230 440 | 15A | 10x38 | FUS-16-L | PF-10x38 | plug-in |
| GS-T 10 / GTS-T 10 | 72 | 230 | 10A | 10x38 | FUS-010 | PF-10x38 | plug-in |
| GS-T 20 / GTS-T 20 | 315 | 230 | 25A | 10x38 | FUS-025 | PF-10x38 | plug-in |
| GS-T 25 / GTS-T 25 | 315 | 230 | 25A | 10x38 | FUS-025 | PF-10x38 | plug-in |

GQ / GS-L / GTS-L / GTS-T / GTS / GS / GTD / GTT / GTF (single-phase with antiparallel thyristor or Triac)

| | | | | 0 | | 0 | |
|---|------------|--------------------|------|----------------------------------|-----------------------|---------------------------|------------|
| Relay | i^2t | Nominal voltage | Fuse | Dimensions (mm) | Fuse order code | Fuse holder order code | Notes |
| GQ / GTS / GS 15 | 450 | 230 480 | 16A | 10x38 | FUS-016 | PF-10x38 | plug-in |
| GTS / GS / GTT / GQ / GT / GTD 25 GTF25 | 645 450 | 230 480 600 | 25A | 10x38 | FUS-025 | PF-10x38 | plug-in |
| GTS / GS / GTT / GT / GTD 40 | 1010 | 230 480 | 40A | 14x51 | FUS-040 | PF-14x51 | plug-in |
| GTF40 / GTF50 | 1800 | 480 600 | 50A | 22x58 | FUS-050 | PF-22x58 | plug-in |
| GTS / GS / GTT / GQ / GT 50 GTF60 | 6600 | 230 480 600 | 63A | 22x58 | FUS-063 | PF-22x58 | plug-in |
| GTS / GS / GTT / GT 60 GTF75 | 6600 | 230 480 600 | 80A | 22x58 | FUS-080 | PF-22x58 | plug-in |
| GTS / GS / GTT / GT 75 | 8000 | 230 480 | 80A | 22x58 | FUS-080 | PF-22x58 | plug-in |
| GTS / GS / GTT / GQ / GT 90 GTF90 | 11200 | 230 480 600 | 100A | 22x58 | FUS-100 | PF-22x58 | plug-in |
| GTS / GS / GTT / GT 120 GTF120 | 11200 | 230 480 600 | 125A | size 0-0-0-TN/80 100x51x30 | FUS-125N | PF-DIN | no plug-in |

| Relay | i^2t | Nominal voltage | Fuse | Dimensions (mm) | Fuse order code | Fuse holder order code | Notes |
|-------------|------------|--------------------|------|--------------------|-----------------------|---------------------------|---------|
| GZ 10A | 100 | 400 | 10A | 10x38 | FUS-10-L | PF-10x38 | plug-in |
| GTZ, GZ 25A | 450 645 | 400 480 | 25A | 12x32 | FUS-025 | PF-10x38 | plug-in |
| GTZ, GZ 40A | 1010 | 480 600 | 40A | 14x51 | FUS-040 | PF-14x51 | plug-in |
| GTZ, GZ 55A | 6600 | 480 600 | 63A | 22x58 | FUS-063 | PF-22x58 | plug-in |

GTZ, GZ (three-phase with antiparallel thyristor)

W21X / W312 / W401 (single-phase with antiparallel thyristor)

| Relay | i^2t | Nominal voltage | Fuse | Dimensions (mm) | Fuse order code | Fuse holder order code | Notes |
|-----------------|---------|--------------------|------|--------------------|-----------------------|---------------------------|------------|
| W21x / W312 25A | 1800 | 660 | 50A | 22x58 | FUS-050 | in the product | plug-in |
| W21x / W312 40A | 11200 | 660 | 63A | 22x58 | FUS-063 | in the product | plug-in |
| W21x 75A | 14450 | 660 | 100A | 22x58 | FUS-100 | in the product | plug-in |
| W21x 100A | 86200 | 660 | 250A | 27x60 | FUS-250 | in the product | plug-in |
| W21x 150A | 86200 | 660 | 250A | 27x60 | FUS-250 | in the product | plug-in |
| W21x 250A | 200000 | 660 | 450A | - | FUS-450N | - | no plug-in |
| W21x 400A | 1125000 | 660 | 630A | - | FUS-630N | - | no plug-in |
| W21x 600A | 1125000 | 660 | 900A | - | FUS-900N | - | no plug-in |
| W401 40A | 11200 | 460 | 63A | 22x58 | FUS-063 | in the product | plug-in |
| W401 100A | 86200 | 460 | 250A | 27x60 | FUS-250 | in the product | plug-in |

GTF >120 / GFW (with antiparallel thyristor)

| Relay | i^2t | Nominal voltage | Fuse | Dimensions (mm) | Fuse order code | Fuse holder order code | Notes |
|------------------|--------|--------------------|------|---------------------------|-----------------------|---------------------------|---------|
| GFW40 | 10000 | 480 600 | 80A | SI 000 DIN80 100x39x20 | FUS-080 S | in the product | plug-in |
| GFW60 | 12000 | 480 600 | 125A | SI 000 DIN80 100x39x20 | FUS-125 S | in the product | plug-in |
| GFW100 | 18000 | 480 600 | 160A | SI 000 DIN80 100x39x20 | FUS-160 S | in the product | plug-in |
| GTF150 GFW150 | 125000 | 480 600 | 200A | SI 000 DIN80 100x39x20 | FUS-200 S | in the product | plug-in |
| GTF200 GFW200 | 320000 | 480 600 | 450A | SI 000 DIN80 100x65x30 | FUS-450 S | in the product | plug-in |
| GTF250 GFW250 | 320000 | 480 600 | 450A | SI 000 DIN80 100x65x30 | FUS-450 S | in the product | plug-in |

ORDER CODE - AVAILABLE MODELS

| FUSES | | | FUSE HOLDERS |
|----------|----------|----------|--------------|
| FUS-06-L | FUS-040 | FUS-630N | PF 10x38 |
| FUS-10-L | FUS-050 | FUS-900N | PF 14x51 |
| FUS-16-L | FUS-063 | FUS-080S | PF 22x58 |
| FUS-010 | FUS-080 | FUS-125S | PF DIN |
| FUS-016 | FUS-100 | FUS-160S | PF 27x60 |
| FUS-015 | FUS-125N | FUS-200S | |
| FUS-025 | FUS-250 | FUS-450S | |
| FUS-030 | FUS-450N | | |



TRAFO - 1 TRAFO - 1B



. 8 .

Power transformer and isolation

Transformer for galvanic isolation of power supply. *Dimensions TRAFO - 1 / TRAFO - 1B* L: 58mm B: 47mm H: 36mm *Dimensions TRAFO - 5 / TRAFO - 5B* L: 67mm B: 52mm H: 45mm

Order code

TRAFO - 1: 3VA transformer, 230/24Vac TRAFO - 1B: 3VA transformer, 24/24Vac TRAFO - 5: 10VA transformer, 230/24Vac TRAFO - 5B: 10VA transformer, 24/24Vac

Current transformer

These transformers are used for currents of 50/60 Hz. The main characteristic of these transformers is the high number of turns in the secondary. This provides a very low secondary current, suitable for an electronic measurement circuit.

The secondary current can be measured as a voltage on a resistor.

| Order code | | | |
|------------|------------|--------------|--|
| 330200 | IN = 50Aac | OUT = 50mAac | |
| 330201 | IN = 25Aac | OUT = 50mAac | |

· Ground terminal for heat sinks

Hole for 2.9 x 9 self-threading screws

The ground terminals attached to GEFRAN heat sinks allow connection of the ground terminal with the screws supplied in the kit.

In

| Туре | Ground terminal Contact area (WxD) * Screw type | Screw type on heat sink side | Heat sink |
|---------|---|---------------------------------|-------------------------------|
| TERM-25 | 9x12 M5 | M4 | DIS-25G |
| TERM-40 | 11,5x12 M5 | M4 | DIS-40G DIS-25GD |
| TERM-60 | 14x16 M5 | M5 | DIS-50G DIS-60G DIS-90G |

* (WxD) = Width (mm) x Depth (mm)



SOLID STATE RELAYS ACCESSORIES

THERMOCONDUCTIVE PASTE

THERMOCONDUCTIVE ADHESIVES

IDENTIFICATION LABELS

ORDER CODE

| Code | Description |
|---|--|
| SIL-1 | Silicone thermoconductive paste for coupling the power module to the heat sink. 100 g tube. |
| Graphite film 35x55mm for solid state relays GQ series. Thickness 0,12mm. 2,1W (m*K). | |
| 312-00 | 200x240mm sheet with n° 25 adhesives. |
| SIL-GS40 | Graphite film 20x55mm for solid state relays GS \leq 40A series. Thickness 0,12mm. 2,1W (m*K). |
| SIL-G540 | 200x240mm sheet with n° 45 adhesives. |
| SIL-GS50 | Graphite film 30x56mm for solid state relays GS \ge 50A series. Thickness 0,12mm. 2,1W (m*K). |
| 312-0350 | 200x240mm sheet with n° 30 adhesives. |
| LAB-1 | Kit with 20 plastic identification labels for GS / GS-T / GTS / GTS-T / GTT / GT / GD / GTD power solid state relays |



SOLID STATE RELAYS ACCESSORIES

CONNECTORS

| ORDER CODE | |
|------------|---|
| Code | Description |
| MORS1 | Two-pin spring connector, plug-in, for GQ control signal |
| MORS2 | Two-pin double spring connector, plug-in, for GQ control signal |
| MORS3 | Two-pin screw connector, plug-in, for GQ control signal |



CONNECTORS FOR INPUTS / OUTPUTS

GTF and GFW

PRODUCT DESCRIPTION

Series of connectors for Geflex inputs/outputs/power supply

| ORDER CODE | |
|---|---------|
| Available for GTF25-120A | |
| Connettore a nove pin per alimentazione e controllo (J1) | COUT4-9 |
| | |
| Available for GTF>120A | |
| Connettore a quattro pin per uscite (J1) | COUT4-4 |
| Connettore a tre pin per alimentazione (J2) | CSIG4-3 |
| Connettore a quattro pin per ingresso digitale (J3) | CSIG4-4 |
| Connettore a quattro pin per ingresso analogico (J4) | COUT4-4 |
| Connettore a due pin per tensione di linea (J8) | CSIG2 |
| Available for GFW | |
| Connettore a nove pin per uscite di allarme e raffreddamento (J1) | COUT4-9 |
| Connettore a tre pin per alimentazione (J2) | CSIG4-3 |
| Connettore a quattro pin per ingressi digitali (J3) | CSIG4-4 |
| Connettore a otto pin per ingressi analogici ausiliari (J4) | CSIG4-8 |
| Connettore a quattro pin per ingresso analogico di comando (J5) | COUT4-4 |
| Connettore a quattro pin per ingresso analogico principale (J6) | COUT4-4 |
| Connettore a due pin per alimentazione ventola (J7) | CSIG4-2 |
| Connettore a due pin per tensione di linea (J10) | CSIG2 |
| | |

Accessories for GTF / GFW CONFIGURATION KIT





Lets you read or write all of the parameters of a single GTF A single software for all models

- · Easy and rapid configuration
- · Saving and management of parameter recipes
- On-line trend and saving of historical data *Component Kit:*
 - Connection cable PC RS232 ‹--> GTF port TTL
- CD SW GF Express installation

ORDER CODE

GF_eXK-0-0-0.....Cod. F043956

KIT PC RS232 / RS 485

KIT PC USB / RS485 or TTL

Kit for GFW and GTF configuration with Modbus RS485 serial option by PC / PLC equipped with RS232 serial (Windows environment).

Lets you read or write all of the parameters of a single GTF / GFW

- A single software for all models
- Easy and rapid configuration
- Saving and management of parameter recipes
- On-line trend and saving of historical data
 Component Kit:
 - Connection cable PC RS232 ----> GTF / GFW RS485 port
 - Serial line converter
 - CD SW GF Express installation

ORDER CODE

GF_eXK-1-1-0.....Cod. F043957

kit for PC via the USB port (Windows environment) for GTF standard configuration (TTL port) for configuration of GFW and GTF with the RS485 option Lets you read or write all of the parameters of a single GTF/GFW A single software for all models

- Easy and rapid configuration
- · Saving and management of parameter recipes
- On-line trend and saving of historical data *Component Kit:*
 - Connection cable PC USB --- , GTF TTL port
 - Connection cablePC USB ---> GTF/GFW RS485 serial port
 - Serial line converter
 - CD SW GF Express installation

ORDER CODE

GF_eXK-2-0-0.....Cod. F049095

The human/machine interface (HMI) is simple, intuitive, and very practical thanks to the optional GFW – OP programming keyboard.

Lets you read or write all of the parameters of a single GFW-M module.

Connected with 9-pin D-SUB connector and housed in the front panel of the GFW-M by means of a magnetic plate.

- Alphameric display: 5 lines x 21 characters.
- Keys to display variable and set parameters.
- Magnetic housing

ORDER CODE

GFW - OP.....Cod. F051664





ORDER CODE

| Cards for Modbus RTU protocol (serial 2) | GFX4-MOD |
|---|------------|
| Cards for Profibus DP protocol (serial 2) | GFX4-PROFI |
| Cards for CANopen protocol (serial 2) | GFX4-CAN |
| Cards for DeviceNet protocol (serial 2) | GFX4-DNET |
| Cards for Ethernet Modbus TCP protocol (serial 2) | GFX4-ETH |
| Cards for Ethernet IP (serial 2) | GFX4-ETH1 |
| Cards for EtherCAT (serial 2) | GFX4-ETH2 |
| Cards for Profinet (serial 2) | GFX4-ETH3 |
| | |

FIELDBUS CARD



COMMUNICATION CONNECTORS / ADAPTERS

PRODUCT DESCRIPTION

Series of connectors for all field bus types (Modbus, Profibus, CANopen, DeviceNet), to facilitate wiring of the communication cable.

Adapters to bring 9 pin SUB connector to front.

ORDER CODE

| Connector for Geflex Master Modbus with cover and inside terminals | СОЛ-М-90 |
|---|----------|
| Connector for Geflex Master Profibus with cover and inside terminals | CON-P-90 |
| Connector for Geflex CANopen with cover and inside terminals | CON-C-90 |
| Connector for DeviceNet with cover and inside terminals | CSIG-5 |
| Connector for serial1 (local bus) type 4p4c/RJ10 | CRJ10 |
| 90° adapter for 9 pin SUBD male connector (Geflex Master CANopen) | AD-9M |
| 90° adapter for 9 pin SUBD female connector (Geflex Master Modbus/Profibus) | AD-9F |
| | |
| | |

CABLES



PRODUCT DESCRIPTION

Series of cables for field bus and to extend connections between Geflex GFXS1/S2.

| ORDER CODE | |
|--|----------------|
| Shielded cable, 1 pair, 22 AWG, L = 1 m Modbus type | 2x0,35 CABLE |
| Shielded cable, 1 pair, 22 AWG, L = 1 m Profibus type | PROFIBUS CABLE |
| Shielded cable, 2 pairs, 22 AWG, L = 1 m CANopen type | CANBUS CABLE |
| 4-pin telephone cable | CV4-RJ10 |
| Cavo I = 0,3m per collegamento seriale Modbus (RJ10) (bus locale) GFX4 <> GFX4 e GTF/GFW <> GTF/GFW | CV4-03 |
| Cable I = 0.3 m for Modbus serial connection (RJ10) (local bus) GFX4 <> GFX4 and GTF/GFW <> GTF/GFW | CV4-1 |
| Cable I = 1 m for Modbus serial connection (RJ10) (local bus) GFX4 <> GFX4 and | |
| GTF/GFW <> GTF/GFW | CV4-2 |
| Cable I = 5 m for Modbus serial connection (RJ10) (local bus) GFX4 <> GFX4 and | |
| GTF/GFW <> GTF/GFW | CV4-5 |
| | |
| | |
| | |
| | |

